#### Use this tear off to measure the thickness of your existing ceiling insulation.



# Choose the right insulation and love the savings

You'll love Earthwool® insulation because it's so easy to install in your ceiling and it will help you save up to 30%\* on your power bill.

This is because Earthwool features high R-values, which is the measure of the thermal performance. The higher the R-value, the better for you and your wallet.

Best of all, if you already have insulation you can add a top up layer of Earthwool to maximise your savings.

### How much insulation do you need?

Existing ceiling insulation	Action required	QLD	ACT/TAS/ NSW/VIC/ SA/WA/NT	
No insulation	Insulate immediately	Earthwool R4.0** ceiling insulation	Earthwool R6.0** ceiling insulation	
<70mm glasswool† or cellulose insulation, <100mm polyester insulation	Add a top up layer of insulation to improve the performance	Earthwool R4.0** ceiling insulation	Earthwool R6.0** ceiling insulation	
70 - 120mm glasswool <sup>†</sup> or cellulose insulation, 100 - 170mm polyester insulation	Below recommended insulation levels. Add a top up layer	Earthwool R2.0 Multi-Use roll	Earthwool R2.0 Multi-Use roll	
120 - 150mm glasswool <sup>†</sup> or cellulose insulation, 170 - 220mm polyester insulation	Adequate insulation, but less than high thermal performance. Top up and future proof your home	Earthwool R2.0 Multi-Use roll	Earthwool R2.0 Multi-Use roll	





**250** 

**200** 

**150** 

100

**50** 

# **EARTHWOOL**

the feel good glasswool insulation

### **R2.0 Multi-Use Roll**





Thickness: 90mm	Width: 430mm	Area: 8.17m²	Fineline: 0810890
	Width: 580mm	Area: 11.02m²	Fineline: 0810891

### **R4.0 Ceiling Batts**





Thickness: 195mm	Width: 430mm	Area: 9.0m²	Fineline: 0810333
	Width: 580mm	Area: 12.11m²	Fineline: 0810335

## **R6.0 Ceiling Batts**





Thickness: 275mm	Width: 430mm	Area: 5.49m²	Fineline: 0810606
	Width: 580mm	Area: 7.4m²	Fineline: 0810607

For more information, visit knaufinsulation.com.au



